State of West Virginia Source Water Assessment and Protection Program Source Water Assessment Report

Revised Report

Central Hampshire PSD-Green Spring PWSID WV3301412

(includes spring sources from an inactive system previously known as Green Spring PSD – Springfield WV3301407)

Hampshire County



Prepared by:

West Virginia Department of Health and Human Resources
Bureau for Public Health
Office of Environmental Health Services
Source Water Protection Unit

June 30, 2013

TABLE OF CONTENTS

Introduction	3
What is the Purpose of this Revised Report?	3
Table 1 Public Water Supply Information	3
What is my Springs's Source Water Protection Area?	4
What is SWAP?	4
What is Susceptibility?	4
How Was my Spring's Susceptibility Determined?	4
Table 2 Source of Your Drinking Water - Hydrogeologic Setting	5
Table 3 Physical Integrity of Spring	5
Table 4 Water Quality and Water Treatment Information	5
Evaluation of Significant Potential Sources of Contamination	6
Potential Contaminant Source Inventory – Green Spring	6
Historic Land Use and Land Use Changes – Green Spring	6
Regional Water Supply and Sewage Treatment – Green Spring	6
Overview of LUST, TRI, and RCRA Occurrences – Green Spring	6
Table 5 Potential Contaminant Sources – Green Spring	7
Table 6 Regulated Sources – Green Spring	7
Potential Contaminant Source Inventory – Springfield	8
Historic Land Use and Land Use Changes- Springfield	8
Regional Water Supply and Sewage Treatment- Springfield	8
Overview of LUST, TRI, and RCRA Occurrences- Springfield	8
Table 7 Potential Contaminant Sources - Springfield	9
Table 8 Regulated Sources - Springfield	10
Next Step:	13
Need additional information?	
Figure 1: Central Hampshire PSD-Green Spring Location Map	13
Figure 2: Central Hampshire PSD-Green Spring Source Water Protection Area with PCS Locations (Topographic Map Background)	14
Figure 3 Central Hampshire PSD-Green Spring Source Water Protection Area with PCS Locations (2011 Aerial Photo Background)	
Figure 4 Central Hampshire PSD-Green Spring Geologic Map	16
Figure 5 Central Hampshire PSD-Springfield Source Water Protection Area with PCS Locations (Topographic Map Background)	17
Figure 6 Central Hampshire PSD-Springfield Source Water Protection Area with PCS Locations (2011 Aerial Photo Background)	18
Figure 7 Central Hampshire PSD-Springfield Geologic Map	19
Appendix A EPA Regulated Sites	20
Glossary of Terms	22

GROUND WATER PUBLIC SUPPLY SYSTEMS SOURCE WATER ASSESSMENT AND PROTECTION (SWAP) PROGRAM REPORT

Prepared by: West Virginia Department of Health and Human Resources (WVDHHR), SWAP Program

INTRODUCTION

What is the Purpose of this Revised Report?

A Source Water Assessment Report was previously prepared for Central Hampshire PSD-Green Spring by West Virginia Department of Health and Human Resources, Bureau for Public Health, Office of Environmental Health Services, Source Water Protection Unit in November 2002. Central Hampshire PSD-Green Spring is located approximately 0.9 miles southeast of Green Spring, Hampshire County, West Virginia along County Route $\frac{1}{1}$ (See Figure 1).

A source location and activity status verification and updated Potential Contaminant Source (PCS) survey was conducted by WVDHHR personnel on May 8, 2013. This revised assessment report is based on this recently updated information. The original delineations, established by WVDHHR consultant RKK, comprised areas of 812 acres for the Green Spring sources and 1,858 acres for the Springfield sources. This revised report maintains these original protection areas.

This concept of source water protection is a preventative approach and complements the effort of proper treatment and disinfection by the individual water supply systems. This assessment is one step in a multilevel approach to ensure a safe future supply of water by understanding what potential threats exist.

This Source Water Assessment Public Summary is to provide information to support local and state efforts to protect public drinking water source and to maintain a safe and dependable water supply for the protection of human health by preventing contamination. The costs of these preventative measures will rarely exceed the cost of remediating a public water supply once it is contaminated.

The emphasis of this assessment is on "source" water rather than the "tap" water. Information on tap water quality is available in the Consumer Confidence Report, which can be obtained from your local water supplier.

This report identifies the significant potential contaminant sources that could threaten source(s) water quality. Your susceptibility ranking does not imply poor water quality. Actual water quality is best reflected by results of regular water tests. Please refer to Table 1 for an informational summary of your public water supply.

Table 1 Public Water Supply Information

PWS Name	Central Hampshire PSD-Green Spring
Address	RR 1, Box 84
City, State, Zip	Augusta, West Virginia 26704
PWSID#	WV3301412
County	Hampshire County
System Type	Community

What is my Springs's Source Water Protection Area?

A spring's source water protection area (SWPA) is the land around the spring where protection activities should be focused. The SWPA is the area that is likely contributing water to the spring. Please refer to Figure 2 for your SWPA.

What is SWAP?

The SWAP, established under the Safe Drinking Water Act, requires every state to:

- Delineate the area from which a public water supply system receives its water;
- Inventory land uses within the recharge areas of all public water supplies;
- Assess the susceptibility of drinking water sources to contamination from these land uses;
- Publicize the results to provide support for improved protection of sources.

The WVDHHR SWAP will complete all of these components of a source water assessment.

What is Susceptibility?

Susceptibility is a measure of your spring's potential to become contaminated by land uses and activities within the SWPA. The purpose of a susceptibility analysis is to provide an overview to actions a public water system may take to further reduce the susceptibility to their drinking water supply. Because public water supply springs occur in various hydrologic settings and have a range of potentially significant contaminant sources, best professional judgment has been used in determining the susceptibility of each public water system to contamination. The possibility of a release from potential contaminant sources is greatly reduced if Best Management Practices (BMP's) are used. The susceptibility determination for your spring did not take into account whether BMP's are being used.

Susceptibility of drinking water does not mean a customer will drink contaminated water. Water suppliers protect drinking water by monitoring and treating water supplies, and using BMP's and source water protection measures to ensure that safe water is delivered to the tap.

How Was my Spring's Susceptibility Determined?

Your spring's susceptibility is based on the following parameters:

- Review of the hydrologic setting (ease of contamination transport through each material present in the local hydrologic setting);
- Review of the physical integrity of the spring(s);
- Review of available ground water quality data;
- Characterization of the potential significant contaminant sources identified in the SWPA;
- Integration of this information to identify the greatest threats to the source water and suggestions of appropriate protection strategies or activities.

Table 2 Source of Your Drinking Water - Hydrogeologic Setting

Spring Name	Geologic Setting/Sensitivity
Green Spring Spring 1 – SP001	
Springfield Spring 1 – SP002	Valley and Ridge (fracture)/ Moderate Sensitivity
Springfield Spring 2 – SP003	

The Central Hampshire PSD-Green Spring water system serves a population of approximately 1,100 residential customers and 27 commercial service connections. The supply is from three active source springs (Green Spring Spring 1, Springfield Spring 1, and Springfield Spring 2). There is one inactive well (Green Spring Well 1). Total raw water production is approximately 93,000 GPD. The source springs are located in the Valley and Ridge Province of West Virginia. The Valley and Ridge Province consists of complex faulted blocks that contain either localized-confined or localized unconfined aquifers, or lack of aquifers. The aquifers may be porous media or fractured rock.

The source spring for Green Spring is located along the axis of the Broad Top Anticline. Rock units within the SWPA include those of the Marcellus Formation and the Oriskany Sandstone (See Figure 4). The source springs for Springfield are located along the axis of the Broad Top Anticline. Rock units within the SWPA include those of the Marcellus Formation and the Oriskany Sandstone (See Figure 7).

The original delineations, established by WVDHHR consultant RKK Engineers, comprised an area of 812 acres for the Green Spring sources (Figure 2) and 1,858 acres for the Springfield sources (Figure 5). RKK used hydrogeologic boundary mapping and numerical modeling with MODFLOW software. This revised report maintains the boundaries of both protection areas. The estimated land areas that may contribute water to the source springs are depicted in the attached maps (Figures 2 and 5) as the Source Water Protection Areas. However, source water and contaminant sources may originate from greater distances than encompassed by these delineations.

Table 3 Physical Integrity of Spring

Spring Name	Source Integrity		
Green Spring Spring 1 – SP001	Unknown		
Springfield Spring 1 – SP002	Unknown		
Springfield Spring 2 – SP003	Unknown		

Springs and wells may vary in their construction characteristics and in the geologic rock types in which they occur. The lack of an effective grout and sanitary seals are avenues by which contaminants from nearby surface water bodies or overland runoff can percolate to springs.

Table 4 Water Quality and Water Treatment Information

Spring Name	Results
Green Spring Spring 1 – SP001	System is classified as GWUDI with
Springfield Spring 1 – SP002	filtration provided to meet required
Springfield Spring 2 – SP003	treatment standards.

The Ground Water Under the Direct Influence (GWUDI) assessment evaluates contaminants that may enter the water drawn directly from the well or spring. Central Hampshire PSD-Green Spring Spring 1 was designated GWUDI by letter dated October 26, 2001. Springfield Spring 1 was designated NOT GWUDI under the initial SWAR dated November 2002. The GWUDI status of Springfield Spring 2 has not been determined and sampling in progress.

The contaminants addressed in this assessment include those regulated under the Safe Drinking Water Act as well as those the WVDHHR has determined may present a concern to public health. Periodic analysis for a variety of bacterial, organic, nitrate, synthetic and inorganic contaminants in the water after treatment may consistently yield values below the maximum contaminant level (MCL) as regulated by the Safe Drinking Water Act. Drinking water that meets MCL standards is associated with little or no health risk. Because sampling requirements are for treated water, the lack of water quality impacts does not necessarily indicate a lack of contamination. This determination is limited by the sampling that is performed for the water system.

All drinking water including bottled water may reasonably be expected to contain small amounts of some contaminants. The presence of contaminants does not necessarily indicate that water poses a health risk. For further information regarding the quality of the system's finished water, please refer to the Consumer Confidence Report or call the Environmental Protection Agency's Safe Drinking Water Hotline at 1-800-426-4791 or contact your local health provider for more information about contaminants and potential health effects.

EVALUATION OF SIGNIFICANT POTENTIAL SOURCES OF CONTAMINATION

Potential Contaminant Source Inventory – Green Spring

The inventory for Central Hampshire PSD-Green Spring consists of approximately 10 significant Potential Contaminant Sources (PCS) of which 9 are considered higher threats to ground water. Please refer to Table 5 for a listing of identified PCSs and Figures 2 and 3 for their locations within the SWPA. Regulated facilities and activities are listed in Table 6, if present within the SWPA.

Historic Land Use and Land Use Changes - Green Spring

Historic land use within the SWPA has been primarily managed forest, residential, and agricultural. Historic aerial photographs were not available to compare with current land use to determine major changes that have occurred within the SWPA.

Regional Water Supply and Sewage Treatment - Green Spring

Groundwater is used in the area for both domestic and public water supply. Septic systems are used for residential sewage treatment within the SWPA.

Overview of LUST, TRI, and RCRA Occurrences – Green Spring

No LUST, TRI, or RCRA sites were identified within the SWPA area. Koppers Inc. operates a wood treatment facility in the alluvial area bordering the North Branch of the Potomac River at Green Spring, just northwest of the SWPA for Central Hampshire PSD-Green Spring. At least three NPDES permitted outfalls and one TRI site are listed for Koppers Inc. at this facility.

Table 5 Potential Contaminant Sources – Green Spring

PCS No.	Map Code	PCS Description	PCS Category	Associated Chemicals	Threat to GW
1	R-4	Residential (single family homes with septic)	Residential	VOC,SOC,NN	Н
2	R-4	Residential (single family homes with septic)	Residential	VOC,SOC,NN	Н
3	R-4	Residential (single family homes with septic)	Residential	VOC,SOC,NN	Н
4	R-4	Residential (single family homes with septic)	Residential	VOC,SOC,NN	Н
5	R-4	Residential (single family homes with septic)	Residential	VOC,SOC,NN	Н
6	R-4	Residential (single family homes with septic)	Residential	VOC,SOC,NN	Н
7	A-2	Animal Feedlots	Agriculture	NN, MP, TO	Н
8	R-4	Residential (single family homes with septic)	Residential	VOC,SOC,NN	Н
	M-30	Wells: abandoned	Municipal	VOC, SOC, MP, PH, NN	Н
	M-7	Highway (County Route ¹ / ₁)	Municipal	PH, VOC, M	M

Please note that the locations of springs/wells and water treatment plants are not displayed on figures due to security reasons.

Table 6 Regulated Sources – Green Spring

Regulated Facilities	
None Identified	

Index to Associated Chemicals is as follows:

MP	Microbiological Pathogens: Total/Fecal Coliform, Viruses, Protozoa	T	Turbidity
NN	Nitrate/Nitrite	TO	Taste and Odor precursors
VOC	Volatile Organic Compounds	R	Radionuclides
HM	Heavy Metals	PH	Petroleum Hydrocarbons
M	Metals	D	Disinfection byproducts
SOC	Synthetic Organic Compounds	ND	Not Determined

Potential Contaminant Source Inventory - Springfield

The inventory for Central Hampshire PSD-Springfield consists of approximately 19 significant Potential Contaminant Sources (PCS) of which 11 are considered higher threats to ground water. Please refer to Table 7 for a listing of identified PCSs and Figures 5 and 6 for their locations within the SWPA. Regulated facilities and activities are listed in Table 8, if present within the SWPA.

Historic Land Use and Land Use Changes-Springfield

Historic land use within the SWPA has been primarily managed forest, residential, and agricultural. Aerial photographs were examined to determine major changes in land use that have occurred during the last 20 years. Between 1989 and 2011, no significant changes in land use occurred within the SWPA.

Regional Water Supply and Sewage Treatment-Springfield

Groundwater is used in the area for both domestic and public water supply. Septic systems are used for residential sewage treatment within the SWPA.

Overview of LUST, TRI, and RCRA Occurrences- Springfield

No LUST, TRI, or RCRA sites were identified within the SWPA area

Table 7 Potential Contaminant Sources - Springfield

PCS No.	Map Code	PCS Description	PCS Category	Associated Chemicals	Threat to GW
1	R-5	Septic Systems (discharging to stream or surface)	Residential	MP, TO, NN	Н
2	R-4	Residential (single family homes with septic)	Residential	VOC,SOC,NN	Н
3	R-4	Residential (single family homes with septic)	Residential	VOC,SOC,NN	Н
4	A-2	Animal Feedlots	Agriculture	NN, MP, TO	Н
5	A-18	Pasture	Agriculture	MP, SOC	L
6	M-6	Fire Stations	Municipal	PH, VOC	L
7	C-48	Underground Storage Tanks (waste water)	Commercial	PH, VOC	Н
8	M-33	Sewage Treatment Impoundments	Municipal	MP, NN, D	Н
9	R-4	Residential (mobile home park)	Residential	VOC,SOC,NN	M
10	R-4	Residential (single family homes with septic)	Residential	VOC,SOC,NN	Н
11	A-7	Crops: other	Agriculture	NN, MP, SOC	L
12	R-4	Residential (single family homes with septic)	Residential	VOC,SOC,NN	Н
13	C-21	Hardware/lumber/parts stores	Commercial	VOV, SOC, HM, M	L
14	R-4	Residential (single family homes with septic)	Residential	VOC,SOC,NN	Н
15	C-3	Auto repair shops	Commercial	PH, M, VOC, HM, SOC H	
16	R-4	Residential (single family homes with septic)	Residential	VOC,SOC,NN H	
17	A-7	Crops: other	Agriculture	NN, MP, SOC L	
18	I-30	Public Utilities (electric power)	Industrial	M, VOC, SOC	M
	M-7	Highway (State Route 28)	Municipal	PH, VOC, M	M

Please note that the locations of springs/wells and water treatment plants are not displayed on figures due to security reasons.

Table 8 Regulated Sources - Springfield

Regulated Facilities

None Identified

Index to Associated Chemicals is as follows:

MP	Microbiological Pathogens: Total/Fecal Coliform, Viruses, Protozoa	T	Turbidity
NN	Nitrate/Nitrite	TO	Taste and Odor precursors
VOC	Volatile Organic Compounds	R	Radionuclides
HM	Heavy Metals	PH	Petroleum Hydrocarbons
M	Metals	D	Disinfection byproducts
SOC	Synthetic Organic Compounds	ND	Not Determined

Some PCSs that are located outside of the SWPA may be included for information purposes. Water supply wells and springs and treatment plants are not identified on the map for security reasons. Some facilities are not located on the SWPA map as they occur over broad geographic areas (agricultural fields, highways, and railroad right-of-ways).

Each significant potential source of contamination has been analyzed and prioritized (low, moderate, and high, unless otherwise noted) relative to its potential to impact the water supply. It is important to note that the links between the PCS and the primary contaminant types are not intended to be comprehensive, but only those commonly associated with the PCS. Any potential source may have one or more types of contaminants associated with the chemicals indicated. Threat rankings are a combination of the perceived risk of the release of a contaminant from a land use area, the migration route of the contaminant to the spring and the relative public health risk of the contaminant itself. The risk rankings are based on the general nature of their activities and the contaminants associated with them, not on facility specific information, such as management practices. This ranking does not take into consideration any unforeseen releases or the dynamics of new PCS's within the delineated SWPA.

A detailed risk assessment of PCS's was beyond the scope of what could be accomplished with available resources and data. A detailed risk analysis is more meaningful when prepared by local decision makers as the bridge from assessment work to protection strategies.

Based on this summarized narrative and susceptibility review for each spring, the overall susceptibility for Green Spring Spring 1, Springfield Spring 1, and Springfield Spring 2 of Central Hampshire PSD-Green Spring indicates a high susceptibility to the identified potential sources of contamination for each source.

For this susceptibility analysis, the State combined the inventory results with other relevant information to decide how likely a water supply may become contaminated by the identified potential sources of contamination. This step makes the assessments useful for communities, since it provides information that local decision-makers use to prioritize approaches for protecting the drinking water supply. It does not mean that these springs are currently contaminated or that these springs are going to be contaminated in the near future, but the potential does exist.

RECOMMENDATION FOR YOUR SOURCE WATER ASSESSMENT AND PROTECTION ACTIVITIES

The following list provides specific recommendations for your source water assessment and protection activities.

- Plan for and complete the proper abandonment of all inactive supply wells.
- Reduce existing chronic threats by obtaining further detailed information concerning Leaking
 Underground Storage Tanks (LUST's) or other Underground Storage Tanks (UST's) within the
 SWPA that are now in service or were in the past. This information should include the type of
 leak detection and corrosion protection currently being used at the facility.
- Investigate what types of preventative pollution measures are being conducted by the industrial or commercial facilities located within the SWPA. Some facilities may already have developed their Groundwater Protection Plan (GPP) for their facility.
- Inspect the SWPA regularly.

- Implement Land Use Planning tools to influence future developments within the SWPA. One way to accomplish this is to join forces with the county to adopt a zoning ordinance that would govern certain uses that are considered high threats to ground water.
- Provide maps of the SWPA to the County Planning Commission or other appropriate county agency to make them aware of the location of proposed development in relation to the water supply source.
- Establish funds to purchase land banks of critical areas (e.g. around sinkholes, wells, springs) to preserve the areas from future development.
- Support and encourage the implementation of Best Management Practices for agricultural areas
 including grazing lands, crop production farms, and orchards. In addition, support information
 can be provided to residents and commercial users to encourage the reduction in over use of
 common pesticides and fertilizers.
- Implement systems for regular collection of hazardous waste from residents. For example, the Eastern Panhandle Soil Conservation District and the Hampshire County Solid Waste Authority has helped organize amnesty days in the past where residents could bring in all types of hazardous wastes without threat of punishment.
- Encourage and implement public education about your water supply regarding its susceptibility to
 contamination and ways to protect. This could come in the form of brochures containing
 information and advice about ground water and the local terrain. For example, the Hampshire
 County Health Department has an on-going educational program that is presented to all fourth
 graders in the county.
- Support and encourage the identification of contamination incidents by citizens.
- Include information regarding contamination and source water protection in mailings to homeowners, including non-emergency contact information. Reduce the amount of septic systems in use by extension of the public sewer system or other approved systems.

NEXT STEP:

Central Hampshire PSD-Green Spring completed a Source Water Protection Plan in November 2011. This plan only considered the spring source at Central Hampshire PSD-Green Spring (Green Spring 1 – SP001). Two additional springs have been added to the source supply following development of the protection plan. These sources were originally part of the inactive Green Spring PSD –Springfield system (WV3301407). The next step in source water protection planning is to update the Source Water Protection Plan (SWPP) plan. The SWPP plan should incorporate the information in this revised Source Water Assessment Report.

NEED ADDITIONAL INFORMATION?

To obtain additional information and/or links, visit the WVDHHP Web site at http://www.wvdhhr.org/oehs/eed/swap/ or call the SWAP Program at 304-558-2981.

*Disclaimer - The coverage presented in this program are under constant revision as new sites or facilities are added. They may not contain all the potential or existing sites or facilities. The West Virginia Bureau for Public Health is not responsible for the use or interpretation of this information.

Maps contained in this source water assessment report are provided as a public service by the West Virginia Bureau for Public Health. The Bureau makes no representation regarding completeness or accuracy of the data presented thereon. Efforts are made to verify and update the data used to generate the maps. However, with data sets of this size and nature, eliminating all errors is difficult. Thus, the user assumes total responsibility for verification.

Please report any inaccuracies on either the map or inventory by calling the SWAP Program at 304-558-2981.




Figure 1: Central Hampshire PSD-Green Spring Location Map




Figure 2: Central Hampshire PSD-Green Spring Source Water Protection Area with PCS Locations (Topographic Map Background)




Figure 3 Central Hampshire PSD-Green Spring Source Water Protection Area with PCS Locations (2011 Aerial Photo Background)




Figure 4 Central Hampshire PSD-Green Spring Geologic Map




Figure 5 Central Hampshire PSD-Springfield Source Water Protection Area with PCS Locations (Topographic Map Background)




Figure 6 Central Hampshire PSD-Springfield Source Water Protection Area with PCS Locations (2011 Aerial Photo Background)




Figure 7 Central Hampshire PSD-Springfield Geologic Map

APPENDIX A EPA REGULATED SITES

CERCLIS:

The Superfund program was created by the Comprehensive Environmental Response, Compensation, and Liability Act, amended by the Superfund Amendments and Reauthorization Act. The acts established authority for the government to respond to the release/threat of release of hazardous wastes, including cleanup and enforcement actions. Long-term cleanups at National Priority List sites last more than a year while short term /emergency cleanups are usually completed in less than a year. CERCLIS is a database used by the U.S. Environmental Protection Agency to track activities conducted under its Superfund program. CERCLIS contains data on potentially hazardous waste sites that have been reported to the EPA. Sites are investigated because of a potential for releasing hazardous substances into the environment are added to the CERCLIS inventory. EPA learns of these sites through notification by the owner, citizen complaints, state and local government identification, and investigations by EPA programs other than Superfund. Specific information is tracked for each individual site.

NPDES:

The National Pollutant Discharge Elimination System (NPDES) database identifies facilities permitted for the operation of point source discharges to surface waters in accordance with the requirements of Section 402 of the Federal Water Pollution Control Act. Point sources are discrete conveyances such as pipes or man-made ditches. Industrial, municipal, and other facilities must obtain permits if their discharges go directly to surface waters. The NPDES permit program controls water pollution by regulating point sources that discharge pollutants into public waters.

RCRA:

This database has records for all hazardous waste, generators, and transporters as defined by the Resource Conservation Recovery Act (RCRA). Hazardous waste as defined by RCRA is waste material that exhibits ignitability, corrosivity, reactivity, or toxicity. Hazardous waste comes in many shapes and forms. Chemical, metal, and furniture manufacturing are some examples of processes that create hazardous waste. RCRA tightly regulates all hazardous waste from "cradle to grave" (i.e., from manufacture to disposal).

TRI:

The Toxics Release Inventory (TRI) is a publicly available EPA database that contains information on toxic chemical releases and other waste management activities reported annually by certain covered industry groups as well as federal facilities. This inventory was established under the Emergency Planning and Community Right-to-Know Act of 1986 (EPCRA) and expanded by the Pollution Prevention Act of 1990.

DEP Regulated Sites:

Abandoned Mine Sites:

Abandoned mine features compiled by the Office of Abandoned Mine Lands and Reclamation (AMLR) of the West Virginia Department of Environmental Protection. The AMLR eliminates damage that occurred from mining operations prior to August 3, 1977 and is funded by the AML fund. It corrects hazardous conditions and reclaims abandoned and forfeited mine sites. Typical AML features include highwalls, portals, refuse piles, and mining structures such as tipples.

Coal Dams:

Point and polygonal mining related impoundments regulated by the West Virginia Department of Environmental Protection's (WVDEP) Division of Mining and Reclamation (DMR).

Solid Waste Facilities:

Seventy-eight (78) municipal and non-municipal waste landfills and waste transfers stations. This data layer was published by West Virginia Department of Environmental Protection's (WVDEP) Division of Waste Management in 2/2002.

Oil and Gas Wells:

The Office of Oil and Gas maintains records on over 40,000 active and 25,000 inactive oil & gas wells. It also manages the Abandoned Well Plugging and Reclamation Program.

GLOSSARY OF TERMS

- Alluvium Sediments deposited by moving rivers.
- Aquifer A formation, group of formations, or part of a formation that contains sufficient saturated permeable materials to yield sufficient, economical quantities of water to wells and springs.
- Conjunctive Delineation In cases where a "ground water" source is designated as Ground Water Under the Direct Influence (GWUDI), an additional delineation in addition to the five (5) year time of travel/recharge delineation for ground water will be completed. The additional delineation will account for stream segments outside of the ground water delineation in cases where the area of surface influence is known or reasonably suspected. It should be noted in karst situations particularly, the surface link is not always an adjacent stream, but could come from a stream miles away. In these cases a conjunctive delineation may not always be performed.
- Contamination The addition to water of any substance or property preventing the use of reducing the usability of the water for ordinary purposes such as drinking, preparing food, bathing, washing, recreation, and cooling
- Flood Plain Any land area susceptible to inundation by floodwater from any source.
- GWUDI or "Ground Water Under the Direct Influence" is defined by the EPA as water beneath the surface of the ground with either a significant occurrence of insects or other macro organisms, algae, or large diameter pathogens such as Giardia lambia or Cryptosporidium or other water characteristic such as turbidity, temperature, pH or conductivity.
- Hydrogeologic Setting Evaluates the sensitivity of an aquifer. The likelihood of a contaminant reaching a well or spring is a function of the ground water flows patterns, the rate of flow, the distance to the source and the hydraulic characteristics of the contaminant. The technical factors include the well(s) pumping rate and spring flow, the direction, slope and elevation of the water table, transmissivity and storativity characteristics of the aquifer, overlaying material and recharge rate for ground water systems.
- 100-year Flood Plain The area adjoining a river, stream, or water course covered by water in the event of a 100 year flood.
- 100 -year Flood The flood having a one percent chance of being equaled or exceeded in magnitude in any given year. Contrary to popular belief it is not a flood occurring once every 100 years.
- Karst A term denoting a formation containing soluble rocks, underground solution passages, sinkholes and springs.
- Infiltration The process of, or fluids, entering the soil and recharging aquifers rather than becoming runoff.
- Maximum Contaminant Level (MCL) Defined as the maximum permissible level of a contaminant in water, which is delivered to any user of a public water system.
- Physical Integrity of the Well or Spring This analysis evaluates and reviews the integrity of the well or spring structures needed to protect the water source from a potential contaminant source(s). It is recognized that protective well construction characteristics can prevent the occurrence of contamination even in the presence of potentially significant contaminant sources. The design and construction of a well should include casing without cracks; tight joints between lengths of casing; adequate grout between the casing and bore hole and location (floodplain or flooding area). A spring must be protected with "shoe box" type lid enclosure that is screened and locked to prevent unauthorized entry. Surface water runoff diversion and land use of the recharge area are paramount elements to evaluate. These features provide reasonable assurance that contaminants will not enter the well or spring through any pathway, and allow operators to focus on the potential for contaminants to migrate through the aquifer and enter into the well(s) or spring. However, even a well(s) and springs constructed to the most exacting standards may

- lose structural integrity with time. Maintenance records of remedial improvements also will be reviewed in evaluation of integrity.
- Potential Contaminant Source (PCS) A facility or container or route of travel that could release a sufficient amount of a harmful contaminant that upon entering an aquifer or surface stream could contaminate it past the level of human health concerns.
- Public Water System is any water system or water supply which regularly supplies or offers to supply, piped water to the public for human consumption, if serving at least an average of twenty-five (25) individuals per day for at least sixty (60) days per year, or which has at least fifteen (15) service connections.
- Recharge Water entering the upper end of a groundwater flow system.
- Remediation The removal of contaminants from soil and/or ground water.
- Sensitivity of the Source Water Protection Area (SWPA) refers to the hydrologic or hydrogeologic characteristics that affect the transport of the contaminant from a source of contamination to a well or intake.
- Source Water Assessment and Protection (SWAP) Program The program established by the 1996
 Amendments to the Safe Drinking Water Act (SDWA) which expanded the initial Wellhead Protection
 Program to all public drinking water supply systems including surface water systems. This program is to
 assess, preserve, and protect the source waters which are used to supply water for public drinking water
 supply systems and to provide a long term availability of an abundant supply of safe water in sufficient
 quantity for present and future citizens of the State. This program also enables the water supply owners,
 consumers, and others to initiate and promote actions to protect their drinking water supplies with the
 developed information.
- Source Water Protection Area (SWPA) refers to the area delineated by the State for a public water system, or including numerous public water systems, whether the source is ground water, surface water or both, as part of the West Virginia SWAP approved by the EPA under section 1453 of the Safe Drinking Water Act.
- Susceptibility The likelihood that a release from a PCS would contaminate and render unusable a drinking water supply such as aquifers or surface steams.
- Unconfined Aquifer An aquifer over which there is no confining layer.
- Water quality Available data will be evaluated to help direct protection activities. If the water quality impact is known, evaluating the source(s) present may help to determine the origin of the contamination and where immediate protection efforts should be focused
- Well(s) refers to ground water intakes including the well structure (i.e., casing, etc) and wellhead.
- Wellhead Protection Area (WHPA) The surface and subsurface area surrounding a water well or well field, supplying a public water system, through which contaminants are reasonably likely to move toward and reach such water well or well field. This area is delineated by the State for ground water source public water systems. The former Wellhead Protection Program (WHPP) is now part of the Source Water Assessment and Protection (SWAP) Program.